

# Contents

|   |           |
|---|-----------|
| <b>Before using the PV-200A/PV-250X/PV-400A/PV-450X for the first time...</b> ..... | <b>1</b>  |
| <b>Chapter 1 Getting Acquainted</b> .....   | <b>9</b>  |
| Make backup copies of important data!   |           |
| Important Precautions   |           |
| Data Errors   |           |
| General Guide   |           |
| Power Supply  |           |
| Using the Backlight   |           |
| Action Control and Stylus   |           |
| Using the Icon Menu   |           |
| Modes   |           |
| <b>Chapter 2 Scheduler</b> .....  | <b>25</b> |
| Entering the Scheduler Mode   |           |
| Inputting New Scheduler Data  |           |
| Reminder Types and Settings   |           |
| Importing Contacts Data Into a Schedule Item  |           |
| Viewing Scheduler Data  |           |
| Date Highlighting   |           |
| Jumping to a Specific Date  |           |
| Renaming To Do Categories   |           |
| <b>Chapter 3 Contacts</b> .....   | <b>55</b> |
| Entering the Contacts Mode  |           |
| Changing the Display Category   |           |
| Latest Calls List   |           |
| Resizing Contacts List Screen Columns   |           |
| Inputting New Contacts Data   |           |
| Viewing Contacts Data   |           |
| Changing Contacts List Screen Contents  |           |
| Changing Contacts Input Screen Contents   |           |
| Managing Untitled Categories and Free Entries                                       |           |
| Copying Data Items Between the Personal and Business Categories                     |           |
| Exporting Contacts Data Into a Schedule Item  |           |

---

|                  |   |            |
|------------------|---|------------|
| <b>Chapter 4</b> | <b>Memo .....</b>                       | <b>69</b>  |
|                  | Entering the Memo Mode                  |            |
|                  | Changing the Display Category           |            |
|                  | Inputting New Memo Data                 |            |
|                  | Viewing Memo Data                       |            |
|                  | Changing the Order within a List Screen |            |
|                  | Renaming Memo Categories                |            |
| <b>Chapter 5</b> | <b>Expense Manager .....</b>            | <b>77</b>  |
|                  | Entering the Expense Manager Mode       |            |
|                  | Inputting a New Transaction             |            |
|                  | Recalling Expense Manager Data          |            |
|                  | Calculating Periodic Totals             |            |
|                  | Managing Payment and Expense Types      |            |
| <b>Chapter 6</b> | <b>Currency Converter .....</b>         | <b>85</b>  |
|                  | Entering the Currency Converter Mode    |            |
|                  | General Currency Conversion             |            |
|                  | Euro Conversion                         |            |
|                  | Setting the Rounding Method             |            |
| <b>Chapter 7</b> | <b>Quick-Memo .....</b>                 | <b>95</b>  |
|                  | Entering the Quick-Memo Mode            |            |
|                  | Quick-Memo Categories                   |            |
|                  | Using the Quick-Memo Drawing Tools      |            |
|                  | Creating a New Quick-Memo               |            |
|                  | Recalling a Quick-Memo                  |            |
|                  | Screen Copy                             |            |
| <b>Chapter 8</b> | <b>Secret Function .....</b>            | <b>105</b> |
|                  | Creating a New Secret Memory Area       |            |
|                  | Using the Secret Memory Area            |            |

---

**Chapter 9 Pop Up Tools ..... 111**

Displaying the Pop Up Tool Screen  
Using the Clock Screen  
Using the Calculator Screen  
Next Appointment Screen

**Chapter 10 Data Communication ..... 121**

Using the Cradle  
Data Communications Between Two PV Units  
Data Communications Between a PV Unit and a BN Unit  
Receiving Data From an SF/CSF/NX Series Unit

**Chapter 11 Game ..... 139**

Entering the Game Mode and Selecting a Game  
Game-1  
Game-2  
General Game Procedures

**Chapter 12 General Operations ..... 147**

Scroll Bars  
Action Control Scrolling  
Menu Bar  
Data Input and Editing  
Closing a Screen  
Using the Quick Find Feature  
Editing Data Items  
Creating a Copy of a Data Item  
Deleting Data  
Searching for Data

---

**Chapter 13** **Configuring the Unit** ..... 165

- Setting the Date, Time, and Auto Power Off Interval
- Turning Sound On and Off
- Setting a Daily Alarm Time
- Setting the Date, Time, Calendar, and Keyboard Formats
- Setting the System Language (PV-250X/PV-450X only)
- Adjusting Display Contrast
- Calibrating the Touch Screen
- Checking Memory Capacity
- Memory Management

**Chapter 14** **Technical Reference** ..... 175

- Date Formats
- Time Formats
- Tool Bars
- Keyboard Formats
- Scheduler Mode Alarms
- Input Limits
- Resetting the PV Unit
- Euro Conversion Rate Presets
- Storage Capacity
- Auto Sort Sequence
- Message Table
- Troubleshooting
- Specifications

**Appendix** ..... 199

- City Name List